



NOTES:

- 1) SEAL CONDUIT ENDS AGAINST MOISTURE ENTRY WITH EXPANSIVE FOAM.
- 2) INSTALL PULL BOX EVERY 500 FEET AND AT ALL ABRUPT DIRECTION CHANGES, NOT TO EXCEED 360° TOTAL BENDS PER NEC.
- 3) FOR TRENCH SECTION REFER TO NMWD STD.1
- 4) INSTALL 3/8" POLYROPE IN CONDUIT.

PARTS LIST:

5	CHRISTY B30 W/FLD30 LID		
4	TELEMETRY CABLE, SIX PAIR, PE-22 SOLID COPPER		
3	2" PVC SCH40 CONDUIT		
2	2" PVC SCH40 CONDUIT LONG RADIUS BEND (90°)		
1	SPLICING KIT, SCOTCH CAST 78-R1 OR EQUAL.		
NORTH MARIN WATER DISTRICT NOVATO, CALIFORNIA			
TELEMETRY CABLE CONDUIT AND PULL BOX			
APPROVED	DATE	REV.	STD. NO.
	5\10\02	1	13